








SPARE CONNECTORS 2008


SPARE PARTS MANUAL

ART.NO.: 3208201

ENGLISH




<p>SPARE CONNECTORS AA-AR</p>  <p style="text-align: right;">1</p>	<p>SPARE CONNECTORS AS-BK</p>  <p style="text-align: right;">2</p>	<p>SPARE CONNECTORS BL-BZ</p>  <p style="text-align: right;">3</p>	<p>SPARE CONNECTORS CA-CP</p>  <p style="text-align: right;">4</p>
<p>SPARE CONNECTORS CQ-DM</p>  <p style="text-align: right;">5</p>	<p>SPARE CONNECTORS DN-EL</p>  <p style="text-align: right;">6</p>		
		<div style="display: flex; align-items: center;">  <p>All information contained is without obligation. KTM-Sportmotorcycle AG particularly reserves the right to modify any equipment, technical specifications, prices, colors, shapes, materials, services, service work, constructions, equipment and the like so as to adapt them to local conditions or to cancel any of the above items, all without previous announcement and without giving reasons. KTM may stop manufacturing certain models without previous notice. KTM shall not be held liable for any deviations of availability and/or ability to deliver, illustrations, descriptions, printing and/or other errors. The illustrated models partly contain extra equipment, which is not applied to standard models. © by KTM-SPORTMOTORCYCLE AG, Mattighofen AUSTRIA; All rights reserved; Reprint, also in extracts, with written allowance of KTM-SPORTMOTORCYCLE AG, Mattighofen only.</p> </div>	



AA



AC



AE



AG




AI



AK




AM




AO



AQ



AB




AD



AF



AH



AJ



AL



AN



AP



AR

FIG	PART NUMBER	DESCRIPTION	QTY
AA	00070000AA	SPARE CONNECTOR AA 20-PINS	X
AB	00070000AB	DIGITAL SPEEDOMETER / DIGITALTACHO	X
AC	00070000AC	SPARE CONNECTOR AC 6-PINS	X
AD	00070000AD	START-SWITCH (LC4/LC8) / STARTSCHALTER (LC4/LC8)	X
AE	00070000AE	FRONT LIGHT / LICHT VORNE	X
AF	00070000AF	SPARE CONNECTOR AD 12-PINS	X
AG	00070000AG	LIGHT-FLASH-SWITCH / LICHT-BLINKERSCHALTER	X
AH	00070000AH	SPARE CONNECTOR AE 4-PINS	X
AI	00070000AI	START RELAY / STARTRELAIS	X
AJ	00070000AJ	SPARE CONNECTOR AF 4-PINS	X
AK	00070000AK	RELAY / RELAIS	X
AL	00070000AL	SPARE CONNECTOR AG 3-PINS	X
AM	00070000AM	TACHOMETER / DREHZAHLMESSER	X
AN	00070000AN	SPARE CONNECTOR AH 2-PINS	X
AO	00070000AO	BRAKE, FLASHER / BREMSE, BLINKER	X
AP	00070000AP	SPARE CONNECTOR AI 2-PINS	X
AQ	00070000AQ	DIODE / DIODEN	X
AR	00070000AR	SPARE CONNECTOR AJ 3-PINS	X
		REAR BRAKE / HINTERBREMSE	X
		SPARE CONNECTOR AK 2-PINS	X
		BRAKE, FLASHER / BREMSE, BLINKER	X
		SPARE CONNECTOR AL 2-PINS	X
		CLUTCH / KUPPLUNG	X
		SPARE CONNECTOR AM 3-PINS	X
		CARBURETOR, GEAR POS. / VERGASER, GETRIEBE	X
		SPARE CONNECTOR AN 4-PINS	X
		SPEEDOMETER / TACHO	X
		SPARE CONNECTOR AO 26-PINS	X
		DIGITALBOX (LC8)	X
		SPARE CONNECTOR AP 6-PINS	X
		IGNITION LOCK / ZÜNDSCHLOSS	X
		SPARE CONNECTOR AQ 1-PINS	X
		OPTIONAL CONNECTOR / ZUSATZSTECKER	X
		SPARE CONNECTOR AR 3-PINS	X
		SIDESTAND, CARB., GEAR / SEITENST., VERGASER, GETRIEBE	X

090001190 / C090001190

* NEW PART

X AS REQUIRED




FIG	PART NUMBER	DESCRIPTION	QTY
AS	000700000AS	SPARE CONNECTOR AS 2-PINS IGNITION SYSTEM / ZÜNDSPULE	X
AT	000700000AT	SPARE CONNECTOR AT 2-PINS PICK UP, GASLEVELSENSOR / BENZINST.GEBER	X
AU	000700000AU	SPARE CONNECTOR AU 2-PINS FAN / LÜFTER	X
AV	000700000AV	SPARE CONNECTOR AV 2-PINS THERMO-SWITCH / THERMOSCHALTER	X
AX	000700000AX	SPARE CONNECTOR AX 2-PINS TEMP. SENSOR / TEMPERATURSENSOR	X
AY	000700000AY	SPARE CONNECTOR AY 1-PINS OIL PRESSURE / ÖLDRUCK	X
AZ	000700000AZ	SPARE CONNECTOR AZ 4-PINS FLASHER REAR / BLINKER HINTEN	X
BA	000700000BA	SPARE CONNECTOR BA 1-PINS OCTANE-ADAPTION / OKTANANPASSUNG	X
BB	000700000BB	SPARE CONNECTOR BB 9-PINS START-SWITCH / STARTSCHALTER	X
BC	000700000BC	SPARE CONNECTOR BC 6-PINS LIGHT FRONT / LICHT VORNE	X
BD	000700000BD	SPARE CONNECTOR BD 12-PINS FLASH-LIGHT-SWITCH / BLINK-LICHTSCHALTER	X
BE	000700000BE	SPARE CONNECTOR BE 3-PINS TACHOMETER TRANSM. / DREHZAHLGEBER	X
BF	000700000BF	SPARE CONNECTOR BF 1-PINS OCTANE-ADAPTION / OKTANANPASSUNG	X
BG	000700000BG	SPARE CONNECTOR BG 3-PINS REAR BRAKE / HINTERBREMSE	X
BH	000700000BH	SPARE CONNECTOR BH 6-PINS IGNITION LOCK / ZÜNDSCHLOSS	X
BI	000700000BI	SPARE CONNECTOR BI 2-PINS REGULATOR / REGLER	X
BJ	000700000BJ	SPARE CONNECTOR BJ 1-PINS OIL PRESSURE / ÖLDRUCK	X
BK	000700000BK	SPARE CONNECTOR BK 4-PINS FLASHER REAR / BLINKER HINTEN	X

090001191 / C090001191

* NEW PART

X AS REQUIRED




FIG	PART NUMBER	DESCRIPTION	QTY
BL	000700000BL	SPARE CONNECTOR BL 2-PINS FLASH. WIR. HARNESS / BLINKERKABELSTRANG	X
BM	000700000BM	SPARE CONNECTOR BM 3-PINS	X
BN	000700000BN	SPARE CONNECTOR BN 1-PINS BATTERY CABLE (LC4) / BATTERIEKABEL (LC4)	X
BO	000700000BO	SPARE CONNECTOR BO 2-PINS LIGHT FRONT (RAC) / LICHT VORNE (RAC)	X
BP	000700000BP	SPARE CONNECTOR BP 4-PINS TACHOMETER / DREHZAHLMESSER	X
BQ	000700000BQ	SPARE CONNECTOR BQ 4-PINS REGULATOR (RAC) / REGLER (RAC)	X
BR	000700000BR	SPARE CONNECTOR BR 4-PINS START-SWITCH (RAC) / STARTSCHALTER (RAC)	X
BS	000700000BS	SPARE CONNECTOR BS 2-PINS FAN CONNECTION / LÜFTERANSCHLUSS	X
BT	000700000BT	SPARE CONNECTOR BT 3-PINS	X
BU	000700000BU	SPARE CONNECTOR BU 18-PINS CDI (HUS, RAC)	X
BV	000700000BV	SPARE CONNECTOR BV 2-PINS FLASH. WIR. HARNESS / BLINKERKABELSTRANG	X
BW	000700000BW	SPARE CONNECTOR BW 3-PINS LIGHT / LICHT	X
BX	000700000BX	SPARE CONNECTOR BX 16-PINS DIGITALBOX (LC4)	X
BY	000700000BY	SPARE CONNECTOR BY 4-PINS IGNITION LOCK (HUS) / ZÜNDSCHLOSS (HUS)	X
BZ	000700000BZ	SPARE CONNECTOR BZ 3-PINS TPS (LC4)	X

090001192 / C090001192

* NEW PART

X AS REQUIRED









FIG	PART NUMBER	DESCRIPTION	QTY
CA	000700000CA	SPARE CONNECTOR CA 4-PINS REGULATOR, LAMBDA / REGLER, LAMBDA	X
CB	000700000CB	SPARE CONNECTOR CB 6-PINS FUSE BOX (LC4) / SICHERUNGSKASTEN(LC4)	X
CC	000700000CC	SPARE CONNECTOR CC 12-PINS LIGHT-FLASHER (DUKE) / LICHT-BLINKER (DUKE)	X
CD	000700000CD	SPARE CONNECTOR CD 2-PINS FAN (DUKE) / LÜFTER (DUKE)	X
CE	000700000CE	SPARE CONNECTOR CE 4-PINS REGULATOR, LAMBDA / REGLER, LAMBDA	X
CF	000700000CF	SPARE CONNECTOR CF 8-PINS CDI (MINI)	X
CG	000700000CG	SPARE CONNECTOR CG 9-PINS SPEEDOMETER (MILITARY) / TACHO (MILITÄR)	X
CH	000700000CH	SPARE CONNECTOR CH 1-PINS BATTERY CABLE (LC4) / BATTERIEKABEL (LC4)	X
CI	000700000CI	SPARE CONNECTOR CI 12-PINS LIGHT (DUKE) / LICHT (DUKE)	X
CJ	000700000CJ	SPARE CONNECTOR CJ 2-PINS LIGHT (DUKE) / LICHT (DUKE)	X
CK	000700000CK	SPARE CONNECTOR CK 2-PINS EXHAUST VALVE / ABGASVENTIL	X
CL	000700000CL	SPARE CONNECTOR CL 2-PINS INJECTION-VALVE / EINSPRITZVENTILE	X
CM	000700000CM	SPARE CONNECTOR CM 2-PINS AIR-TEMP. SENSOR / LUFTTEMP.SENSOR	X
CN	000700000CN	SPARE CONNECTOR CN 9-PINS REAR LIGHT (LC8-D) / RÜCKLICHT (LC8-D)	X
CO	000700000CO	SPARE CONNECTOR CO 34-PINS ECU (LC8-D) / STEUERGERÄT (LC8-D)	X
CP	000700000CP	SPARE CONNECTOR CP 16-PINS AIRBOX	X

090001193 / C090001193

* NEW PART

X AS REQUIRED




FIG	PART NUMBER	DESCRIPTION	QTY
CQ	000700000CQ	SPARE CONNECTOR CQ 16-PINS	X
CR	000700000CR	SPARE CONNECTOR CR 1-PINS	X
CS	000700000CS	IGNITION SYSTEM / ZÜNDSPULE	X
CU	000700000CU	SPARE CONNECTOR CU 4-PINS	X
CV	000700000CV	HANDLEBAR SWITCH / LENKERSCHALTER	X
CW	000700000CW	SPARE CONNECTOR CV 4-PINS	X
CX	000700000CX	IGNITION LOCK (HUS) / ZÜNDSCHLOSS (HUS)	X
CY	000700000CY	SPARE CONNECTOR CW 2-PINS	X
CZ	000700000CZ	SPEEDOMETER (RAC) / TACHO (RAC)	X
DA	000700000DA	SPARE CONNECTOR CX 2-PINS	X
DB	000700000DB	SPEEDOMETER (RAC) / TACHO (RAC)	X
DC	000700000DC	SPARE CONNECTOR CY 3-PINS	X
DD	000700000DD	SPEEDOMETER (RAC) / TACHO (RAC)	X
DE	000700000DE	SPARE CONNECTOR CZ 3-PINS	X
DF	000700000DF	SPEEDOMETER (RAC) / TACHO (RAC)	X
DG	000700000DG	SPARE CONNECTOR DA 4-PINS	X
DI	000700000DI	SPEEDOMETER (RAC) / TACHO (RAC)	X
DJ	000700000DJ	SPARE CONNECTOR DB 4-PINS	X
DK	000700000DK	SPARE CONNECTOR DC 3-PINS	X
DM	000700000DM	REGULATOR (LC4) / REGLER (LC4)	X
		SPARE CONNECTOR DD 3-PINS	X
		REGULATOR (LC4) / REGLER (LC4)	X
		SPARE CONNECTOR DE 1-PINS	X
		IGNITION LOCK (HUS) / ZÜNDSCHLOSS (HUS)	X
		SPARE CONNECTOR DF 2-PINS	X
		SPARE CONNECTOR DG 4-PINS	X
		LIGHT (RAC) / LICHT (RAC)	X
		SPARE CONNECTOR DI 2-PINS	X
		SPARE CONNECTOR DJ 18-PINS	X
		ALARM SYSTEM / ALARMANLAGE	X
		SPARE CONNECTOR DK 18-PINS	X
		ALARM SYSTEM / ALARMANLAGE	X
		SPARE CONNECTOR DM 2-PINS	X
		ABS-SENSOR CONNECTOR / ABS SENSORENSTECKER	X

090001194 / C090001194

* NEW PART

X AS REQUIRED




FIG	PART NUMBER	DESCRIPTION	QTY
DN	000700000DN	SPARE CONNECTOR DN 8-PINS	X
DO	000700000DO	ABS-SWITCH, STARTER INTERLOCK	X
DP	000700000DP	SPARE CONNECTOR DP 3-PINS	X
DQ	000700000DQ	PRESSURE SENSOR (LC8 ADV) / DRUCKSENSOR	X
DR	000700000DR	SPARE CONNECTOR DR 8-PINS	X
DV	000700000DV	THROTTLE CONTROL MOTOR (LC4) / DROSSELKLAPPENSTELLMOTOR	X
DW	000700000DW	FUEL PUMP (LC4) / BENZINPUMPE (LC4)	X
DX	000700000DX	SPARE CONNECTOR DX 3-PINS	X
EA	000700000EA	MAP-SENSOR (LC4)	X
EB	000700000EB	SPARE CONNECTOR EA 2-PINS	X
EC	000700000EC	ABS FUSE-HOLDER / ABS SICHERUNGSHALTER	X
ED	000700000ED	SPARE CONNECTOR EB 4-PINS	X
EF	000700000EF	RELAY CONNECTOR / RELAIS STECKER	X
EG	000700000EG	SPARE CONNECTOR EC 3-PINS	X
EJ	000700000EJ	WATER-TEMP.SENSOR / WASSERTEMP.SENSOR	X
EK	000700000EK	SPARE CONNECTOR ED 32-PINS	X
EL	000700000EL	SPEEDOMETER / TACHO	X
		SPARE CONNECTOR EF 14-PINS	X
		ALARM SYSTEM / ALARMANLAGE	X
		SPARE CONNECTOR EG 14-PINS	X
		ALARM SYSTEM / ALARMANLAGE	X
		SPARE CONNECTOR EJ 2-PINS	X
		SPARE CONNECTOR EK 2-PINS	X
		SPARE CONNECTOR EL 2-PINS	X

090001195 / C090001195

* NEW PART

X AS REQUIRED





KTM-Sportmotorcycle AG
A-5230 Mattighofen
www.ktm.at

KTM Group Partner



3208201



Art.Nr.: 3208201 3/2008