

# SPARE CONNECTORS











SPARE PARTS MANUAL

ART.NO.: 3208201

ENGLISH





<p><b>SPARE CONNECTORS AA-AN</b></p>  <p style="text-align: right;"><b>2</b></p>	<p><b>SPARE CONNECTORS AO-BC</b></p>  <p style="text-align: right;"><b>3</b></p>	<p><b>SPARE CONNECTORS BD-BQ</b></p>  <p style="text-align: right;"><b>4</b></p>	<p><b>SPARE CONNECTORS BR-CD</b></p>  <p style="text-align: right;"><b>5</b></p>
<p><b>SPARE CONNECTORS CE-CR</b></p>  <p style="text-align: right;"><b>6</b></p>	<p><b>SPARE CONNECTORS CS-DG</b></p>  <p style="text-align: right;"><b>7</b></p>	<p><b>SPARE CONNECTORS DI-EB</b></p>  <p style="text-align: right;"><b>8</b></p>	<p><b>SPARE CONNECTORS EC-FB</b></p>  <p style="text-align: right;"><b>9</b></p>
<p><b>SPARE CONNECTORS FC-FE</b></p>  <p style="text-align: right;"><b>10</b></p>	<div style="display: flex; align-items: center;">  <p>                     All information contained is without obligation. KTM-Sportmotorcycle-AG particularly reserves the right to modify any equipment, technical specifications, prices, colors, shapes, materials, services, service work, constructions, equipment and the like so as to adapt them to local conditions or to cancel any of the above items, all without previous announcement and without giving reasons. KTM may stop manufacturing certain models without previous notice. KTM shall not be held liable for any deviations of availability and/or ability to deliver, illustrations, descriptions, printing and/or other errors. The illustrated models partly contain extra equipment, which is not applied to standard models.                      © by KTM-SPORTMOTORCYCLE AG, Mattighofen AUSTRIA; All rights reserved; Reprint, also in extracts, with written allowance of KTM-SPORTMOTORCYCLE-AG, Mattighofen only.                 </p> </div>		

# SPARE CONNECTORS AA-AN

# SPARE CONNECTORS




FIG	PART NUMBER	DESCRIPTION	QTY
AA	000700000AA	SPARE CONNECTOR AA 20-PINS DIGITAL SPEEDOMETER (LC4, LC8) / DIGITALTACHO (LC4, LC8)	X
AB	000700000AB	SPARE CONNECTOR AB 9-PINS START SWITCH (LC8) / STARTSCHALTER (LC8)	X
AC	000700000AC	SPARE CONNECTOR AC 6-PINS HEAD LIGHT / SCHEINWERFER	X
AD	000700000AD	SPARE CONNECTOR AD 12-PINS LIGHT-, FLASH-SWITCH / LICHT-, BLINKERSCHALTER	X
AE	000700000AE	SPARE CONNECTOR AE 4-PINS START RELAY / STARTRELAIS	X
AF	000700000AF	SPARE CONNECTOR AF 4-PINS RELAY / RELAIS	X
AG	000700000AG	SPARE CONNECTOR AG 3-PINS TACHOMETER / DREHZAHLMESSER	X
AH	000700000AH	SPARE CONNECTOR AH 2-PINS BRAKE, FLASHER / BREMSE, BLINKER	X
AI	000700000AI	SPARE CONNECTOR AI 2-PINS DIODE / DIODE	X
AJ	000700000AJ	SPARE CONNECTOR AJ 3-PINS REAR BRAKE / HINTERBREMSE	X
AK	000700000AK	SPARE CONNECTOR AK 2-PINS BRAKE, FLASHER / BREMSE, BLINKER	X
AL	000700000AL	SPARE CONNECTOR AL 2-PINS CLUTCH / KUPPLUNG	X
AM	000700000AM	SPARE CONNECTOR AM 3-PINS CARBURETOR, GEARS / VERGASER, GÄNGE	X
AN	000700000AN	SPARE CONNECTOR AN 4-PINS SPEEDOMETER / TACHO	X

100001190\_01 / C100001190\_01

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS AO-BC

# SPARE CONNECTORS





FIG	PART NUMBER	DESCRIPTION	QTY
AO	000700000AO	SPARE CONNECTOR AO 26-PINS CONTROL UNIT (LC8) / STEUERGERÄT (LC8)	X
AP	000700000AP	SPARE CONNECTOR AP 6-PINS IGNITION LOCK / ZÜNDSCHLOSS	X
AQ	000700000AQ	SPARE CONNECTOR AQ 1-PIN OPTIONAL CONNECTOR / ZUSATZSTECKER	X
AR	000700000AR	SPARE CONNECTOR AR 3-PINS SIDE STAND, CARBURETOR / SEITENSTÄNDER, VERGASER	X
AS	000700000AS	SPARE CONNECTOR AS 2-PINS IGNITION COIL / ZÜNDSPULE	X
AT	000700000AT	SPARE CONNECTOR AT 2-PINS PICK UP, GAS LEVEL SENSOR / PICK UP, BENZINSTANDSGEBER	X
AU	000700000AU	SPARE CONNECTOR AU 2-PINS FAN / LÜFTER	X
AV	000700000AV	SPARE CONNECTOR AV 2-PINS THERMO-SWITCH / THERMOSCHALTER	X
AX	000700000AX	SPARE CONNECTOR AX 2-PINS TEMPERATURE SENSOR / TEMPERATURSENSOR	X
AY	000700000AY	SPARE CONNECTOR AY 1-PIN OIL PRESSURE / ÖLDRUCK	X
AZ	000700000AZ	SPARE CONNECTOR AZ 4-PINS FLASHER REAR / BLINKER HINTEN	X
BA	000700000BA	SPARE CONNECTOR BA 1-PIN OCTANE-ADAPTION / OKTANANPASSUNG	X
BB	000700000BB	SPARE CONNECTOR BB 9-PINS COUNTERPART START-SWITCH / GEGENSTÜCK STARTSCHALTER	X
BC	000700000BC	SPARE CONNECTOR BC 6-PINS COUNTERPART HEAD LIGHT / GEGENSTÜCK SCHEINWERFER	X

100001190\_02 / C100001190\_02

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS BD-BQ

# SPARE CONNECTORS




FIG	PART NUMBER	DESCRIPTION	QTY
BD	000700000BD	SPARE CONNECTOR BD 12-PINS COUNTERPART LIGHT-, FLASH-SWITCH / GEGENSTÜCK LICHT-, BLINKERSCHALTER	X
BE	000700000BE	SPARE CONNECTOR BE 3-PINS COUNTERPART SPEED SENSOR / GEGENSTÜCK DREHZAHLGEBER	X
BF	000700000BF	SPARE CONNECTOR BF 1-PIN COUNTERPART OCTANE-ADAPTION / GEGENSTÜCK OKTANANPASSUNG	X
BG	000700000BG	SPARE CONNECTOR BG 3-PINS COUNTERPART REAR BRAKE / GEGENSTÜCK HINTERBREMSE	X
BH	000700000BH	SPARE CONNECTOR BH 6-PINS COUNTERPART IGNITION LOCK / GEGENSTÜCK ZÜNDSCHLOSS	X
BI	000700000BI	SPARE CONNECTOR BI 2-PINS COUNTERPART REGULATOR / GEGENSTÜCK REGLER	X
BJ	000700000BJ	SPARE CONNECTOR BJ 1-PIN COUNTERPART OIL PRESSURE / GEGENSTÜCK ÖLDRUCK	X
BK	000700000BK	SPARE CONNECTOR BK 4-PINS COUNTERPART FLASHER REAR / GEGENSTÜCK BLINKER HINTEN	X
BL	000700000BL	SPARE CONNECTOR BL 2-PINS FLASHER WIRING HARNESS / BLINKERKABELSTRANG	X
BM	000700000BM	SPARE CONNECTOR BM 3-PINS LIGHT 97/98 (DUKE) / LICHT 97/98 (DUKE)	X
BN	000700000BN	SPARE CONNECTOR BN 1-PIN COUNTERPART BATTERY CABLE (LC4) / GEGENSTÜCK BATTERIEKABEL (LC4)	X
BO	000700000BO	SPARE CONNECTOR BO 2-PINS HEAD LIGHT (RAC) / SCHEINWERFER (RAC)	X
BP	000700000BP	SPARE CONNECTOR BP 4-PINS TACHOMETER / DREHZAHLMESSER	X
BQ	000700000BQ	SPARE CONNECTOR BQ 4-PINS REGULATOR (RAC) / REGLER (RAC)	X

100001190\_03 / C100001190\_03

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS BR-CD

# SPARE CONNECTORS




FIG	PART NUMBER	DESCRIPTION	QTY
BR	000700000BR	SPARE CONNECTOR BR 4-PINS START-SWITCH (RAC) / STARTSCHALTER (RAC)	X
BS	000700000BS	SPARE CONNECTOR BS 2-PINS FAN CONNECTION / LÜFTERANSCHLUSS	X
BT	000700000BT	SPARE CONNECTOR BT 3-PINS COUNTERPART FLASHER WIRING HARNESS (ATV) / GEGENSTÜCK BLINKERKABELSTRANG (ATV)	X
BU	000700000BU	SPARE CONNECTOR BU 18-PINS CDI (HUS, RAC) / CDI (HUS, RAC)	X
BV	000700000BV	SPARE CONNECTOR BV 2-PINS FLASHER WIRING HARNESS / BLINKERKABELSTRANG	X
BW	000700000BW	SPARE CONNECTOR BW 3-PINS LIGHT / LICHT	X
BX	000700000BX	SPARE CONNECTOR BX 16-PINS IGNITION BOX (LC4) / ZÜNDBOX (LC4)	X
BY	000700000BY	SPARE CONNECTOR BY 4-PINS IGNITION LOCK (HUS) / ZÜNDSCHLOSS (HUS)	X
BZ	000700000BZ	SPARE CONNECTOR BZ 3-PINS THROTTLE POSITION SENSOR (LC4) / DROSSELKLAPPENSSENSOR (LC4)	X
CA	000700000CA	SPARE CONNECTOR CA 4-PINS REGULATOR, LAMBDA SENSOR / REGLER, LAMBDA-SONDE	X
CB	000700000CB	SPARE CONNECTOR CB 6-PINS FUSE BOX (LC4) / SICHERUNGSKASTEN (LC4)	X
CC	000700000CC	SPARE CONNECTOR CC 12-PINS LIGHT, FLASHER (DUKE) / LICHT, BLINKER (DUKE)	X
CD	000700000CD	SPARE CONNECTOR CD 2-PINS FAN (DUKE) / LÜFTER (DUKE)	X

100001190\_04 / C100001190\_04

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS CE-CR

# SPARE CONNECTORS









FIG	PART NUMBER	DESCRIPTION	QTY
CE	000700000CE	SPARE CONNECTOR CE 4-PINS COUNTERPART REGULATOR, LAMBDA SENSOR / GEGENSTÜCK REGLER, LAMBDA-SONDE	X
CF	000700000CF	SPARE CONNECTOR CF 8-PINS CDI (MINI) / CDI (MINI)	X
CG	000700000CG	SPARE CONNECTOR CG 9-PINS SPEEDOMETER (MIL) / TACHO (MIL)	X
CH	000700000CH	SPARE CONNECTOR CH 1-PIN BATTERY CABLE (LC4) / BATTERIEKABEL (LC4)	X
CI	000700000CI	SPARE CONNECTOR CI 12-PINS COUNTERPART LIGHT, FLASHER (DUKE) / GEGENSTÜCK LICHT, BLINKER (DUKE)	X
CJ	000700000CJ	SPARE CONNECTOR CJ 2-PINS LIGHT (DUKE) / LICHT (DUKE)	X
CK	000700000CK	SPARE CONNECTOR CK 2-PINS EXHAUST VALVE / ABGASVENTIL	X
CL	000700000CL	SPARE CONNECTOR CL 2-PINS INJECTION VALVES / EINSPRITZVENTILE	X
CM	000700000CM	SPARE CONNECTOR CM 2-PINS AIR TEMPERATURE SENSOR / LUFTTEMPERATURSENSOR	X
CN	000700000CN	SPARE CONNECTOR CN 9-PINS REAR LIGHT (LC8) / RÜCKLICHT (LC8)	X
CO	000700000CO	SPARE CONNECTOR CO 34-PINS CONTROL UNIT (LC8) / STEUERGERÄT (LC8)	X
CP	000700000CP	SPARE CONNECTOR CP 16-PINS AIRBOX / LUFTFILTERKASTEN	X
CQ	000700000CQ	SPARE CONNECTOR CQ 16-PINS AIRBOX (WIRING HARNESS SIDE) / LUFTFILTERKASTEN (KABELSTRANG SEITE)	X
CR	000700000CR	SPARE CONNECTOR CR 1-PIN IGNITION COIL / ZÜNDSPULE	X

100001190\_05 / C100001190\_05

\* NEW PART

X AS REQUIRED



# SPARE CONNECTORS CS-DG

# SPARE CONNECTORS




FIG	PART NUMBER	DESCRIPTION	QTY
CS	000700000CS	SPARE CONNECTOR CS 9-PINS COUNTERPART SPEEDOMETER (MIL) / GEGENSTÜCK TACHO (MIL)	X
CU	000700000CU	SPARE CONNECTOR CU 4-PINS CDI (2-STROKE) / CDI (2-TAKT)	X
CV	000700000CV	SPARE CONNECTOR CV 4-PINS COUNTERPART IGNITION LOCK (HUS) / GEGENSTÜCK ZÜNDSCHLOSS (HUS)	X
CW	000700000CW	SPARE CONNECTOR CW 2-PINS SPEEDOMETER (RAC) / TACHO (RAC)	X
CX	000700000CX	SPARE CONNECTOR CX 2-PINS SPEEDOMETER (RAC) / TACHO (RAC)	X
CY	000700000CY	SPARE CONNECTOR CY 3-PINS SPEEDOMETER (RAC) / TACHO (RAC)	X
CZ	000700000CZ	SPARE CONNECTOR CZ 3-PINS SPEEDOMETER (RAC) / TACHO (RAC)	X
DA	000700000DA	SPARE CONNECTOR DA 4-PINS SPEEDOMETER (RAC) / TACHO (RAC)	X
DB	000700000DB	SPARE CONNECTOR DB 4-PINS SPEEDOMETER (RAC) / TACHO (RAC)	X
DC	000700000DC	SPARE CONNECTOR DC 3-PINS REGULATOR (LC4) / REGLER (LC4)	X
DD	000700000DD	SPARE CONNECTOR DD 3-PINS COUNTERPART REGULATOR (LC4) / GEGENSTÜCK REGLER (LC4)	X
DE	000700000DE	SPARE CONNECTOR DE 1-PIN IGNITION LOCK (HUS) / ZÜNDSCHLOSS (HUS)	X
DF	000700000DF	SPARE CONNECTOR DF 2-PINS PURGE VALVE / SPÜLVENTIL	X
DG	000700000DG	SPARE CONNECTOR DG 4-PINS COUNTERPART LIGHT (RAC) / GEGENSTÜCK LICHT (RAC)	X

100001190\_06 / C100001190\_06

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS DI-EB

# SPARE CONNECTORS





FIG	PART NUMBER	DESCRIPTION	QTY
DI	00070000DI	SPARE CONNECTOR DI 2-PINS POSITION LIGHT SOCKET / STANDLICHTFASSUNG	X
DJ	00070000DJ	SPARE CONNECTOR DJ 18-PINS ALARM SYSTEM / ALARMANLAGE	X
DK	00070000DK	SPARE CONNECTOR DK 18-PINS COUNTERPART ALARM SYSTEM / GEGENSTÜCK ALARMANLAGE	X
DM	00070000DM	SPARE CONNECTOR DM 2-PINS ABS-SENSOR / ABS-SENSOR	X
DN	00070000DN	SPARE CONNECTOR DN 8-PINS ABS-SWITCH / ABS-SCHALTER	X
DO	00070000DO	SPARE CONNECTOR DO 8-PINS COUNTERPART ABS-SWITCH / GEGENSTÜCK ABS-SCHALTER	X
DP	00070000DP	SPARE CONNECTOR DP 3-PINS PRESSURE SENSOR (LC8) / DRUCKSENSOR (LC8)	X
DQ	00070000DQ	SPARE CONNECTOR DQ 2-PINS INJECTION NOZZLE (LC4) / EINSPRITZDÜSE (LC4)	X
DR	00070000DR	SPARE CONNECTOR DR 8-PINS THROTTLE POSITION CONTROL MOTOR (LC4) / DROSSELKLAPPENSTELLMOTOR (LC4)	X
DV	00070000DV	SPARE CONNECTOR DV 2-PINS FUEL PUMP (LC4) / BENZINPUMPE (LC4)	X
DW	00070000DW	SPARE CONNECTOR DW 2-PINS SAS-VALVE (LC4) / SLS-VENTIL (LC4)	X
DX	00070000DX	SPARE CONNECTOR DX 3-PINS THROTTLE BODY (LC4) / DROSSELKLAPPENKÖRPER (LC4)	X
EA	00070000EA	SPARE CONNECTOR EA 2-PINS FUSE HOLDER ABS / SICHERUNGSTRÄGER ABS	X
EB	00070000EB	SPARE CONNECTOR EB 4-PINS RELAY / RELAIS	X

100001190\_07 / C100001190\_07

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS EC-FB

# SPARE CONNECTORS






FIG	PART NUMBER	DESCRIPTION	QTY
EC	000700000EC	SPARE CONNECTOR EC 3-PINS WATER TEMPERATURE SENSOR / WASSERTEMPERATURENSOR	X
ED	000700000ED	SPARE CONNECTOR ED 32-PINS SPEEDOMETER 07 / TACHO 07	X
EF	000700000EF	SPARE CONNECTOR EF 14-PINS ALARM SYSTEM / ALARMANLAGE	X
EG	000700000EG	SPARE CONNECTOR EG 14-PINS COUNTERPART ALARM SYSTEM / GEGENSTÜCK ALARMANLAGE	X
EJ	000700000EJ	SPARE CONNECTOR EJ 2-PINS THUMB GAS (ATV) / DAUMENGAS (ATV)	X
EK	000700000EK	SPARE CONNECTOR EK 2-PINS COUNTERPART THUMB GAS (ATV) / GEGENSTÜCK DAUMENGAS (ATV)	X
EL	000700000EL	SPARE CONNECTOR EL 2-PINS ANTENNA IMMOBILIZER / ANTENNE WEGFAHRSPERRE	X
EO	000700000EO	SPARE CONNECTOR EO 3-PINS IGNITION COIL / ZÜNDSPULE	X
EU	000700000EU	SPARE CONNECTOR EU 4-PINS COUNTERPART CONNECTOR-RELAIS / GEGENSTÜCK STECKER-RELAIS	X
EV	000700000EV	SPARE CONNECTOR EV 26-PINS SPEEDOMETER (RC8) / TACHO (RC8)	X
EW	000700000EW	SPARE CONNECTOR EW 4-PINS HEAD LIGHT (RC8) / SCHEINWERFER (RC8)	X
EX	000700000EX	SPARE CONNECTOR EX 3-PINS THROTTLE POSITION CONTROL MOTOR (HUS) / DROSSELKLAPPENSTELLMOTOR (HUS)	X
EY	000700000EY	SPARE CONNECTOR EY 3-PINS VOLTAGE REGULATOR (HUS) / SPANNUNGSREGLER (HUS)	X
FB	000700000FB	SPARE CONNECTOR FB 4-PINS COUNTERPART VOLTAGE REGULATOR (HUS) / GEGENSTÜCK SPANNUNGSREGLER (HUS)	X

100001190\_08 / C100001190\_08

\* NEW PART

X AS REQUIRED

# SPARE CONNECTORS FC-FT

# SPARE CONNECTORS






FIG	PART NUMBER	DESCRIPTION	QTY
FC	00070000FC	SPARE CONNECTOR FC 2-PINS COUNTERPART IGNITION COIL / GEGENSTÜCK ZÜNDSPULE	X
FE	00070000FE	SPARE CONNECTOR FE 2-PINS COUNTERPART EXHAUST VALVE / GEGENSTÜCK ABGASVENTIL	X
FF	00070000FF	SPARE CONNECTOR FF 1-PIN HORN / HUPE	X
FG	00070000FG	SPARE CONNECTOR FG 1-PIN BRAKE LIGHT SWITCH FRONT / BREMSLICHTSCHALTER VORNE	X
FH	00070000FH	SPARE CONNECTOR FH 16-PINS FUSE CARRIER ADVENTURE/SM / SICHERUNGSHALTER ADVENTURE/SM	X
FJ	00070000FJ	SPARE CONNECTOR FJ 2-PINS SECURE ELEMENT FOR LITTLEFUSE / SICHERUNGSELEMENT FÜR LITTLEFUSE	X
FL	00070000FL	SPARE CONNECTOR 1-PIN IGNITION COIL PLUS (LC4) / ZÜNDSPULE + (LC4)	X
FM	00070000FM	SPARE CONNECTOR 1-PIN IGNITION COIL MINUS (LC4) / ZÜNDSPULE – (LC4)	X
FN	00070000FN	SPARE CONNECTOR 2-PINS SECURE ELEMENT FOR FUSE / SICHERUNGSELEMENT FÜR FUSE	X
FO	00070000FO	SPARE CONNECTOR FO 2-PINS INDICATOR LIGHT / KONTROLLAMPE	X
FP	00070000FP	SPARE CONNECTOR FP 1-PIN GROUND EXC LIGHT / MASSE EXC SCHEINWERFER	X
FQ	00070000FQ	SPARE CONNECTOR FQ 1-PIN FUSE-HOLDER FOR FAN / SICHERUNGSHALTER LÜFTERKABELSTRANG	X
FR	00070000FR	SPARE CONNECTOR FR 4-PINS BACKLIGHT RALLEY / RÜCKLICHT RALLEY	X
FS	00070000FS	SPARE CONNECTOR FS 4-PINS 771 EFI WIRING HARNESS / 771 EFI KABELSTRANG	X
FT	00070000FT	SPARE CONNECTOR FT 3-PINS THROTTLE POS. SENSOR DUKE R / DROSSELKLAPENKÖRPER DUKE R	X

100001190\_09 / C100001190\_09

\* NEW PART

X AS REQUIRED